

## Overload Shutdown / Efficiency Meter Rev F Assembly / Parts List

C701	33pF	
C702	33pF	
C703	47uF/16v	
C704	33pF	
C705	10uF/16V	
C706	10uF/16V	
C707	220pF	
C708	33pF	
C709	220pF	
C710	220pF	
C711	0 (not installed)	
C712	0 (not installed)	
C713	0.47	
C715	10uF/16V	
C719	100uF/25V	
C721	100uF/25V	
C723	100uF/25V	
C724	100uF/25V	
C725	0.001	
C726	0.001	
D701	1n4007	
D702	1n4007	
D703	1n4007	
D704	1n4007	
D705	1n4007	
D708	1n4007	
D709	1n4007	
D710	1n4007	
M700	1mA	
Q701	2n3904	
Q702	2n3904	
Q703	2n3904	
Q705	2n3904	
Q706	2n3904	
R701	1 Meg, 1/2 watt, Precision resistor	
R702	100k Pot	
R703	10k	
R704	10k	
R705	1k	

	R706	5k Pot	
	R707	10k	
	R708	50k Pot	
	R709	10k	
	R710	47k	
	R711	10k	
	R712	240k	
	R713	1k Pot	
	R714	390	
	R715	100k Pot	
	R716	47k	
	R717	10k	
	R718	10k	
	R719	1k	
	R720	1k Pot	
	R721	10k	
	R722	10k	
	R723	1k	
	R724	1k	
	R725	1k	
	R726	10k	
	R727	100k	
	R731	1k	
	R732	1k	
	R735	0 ohms (jumper)	
	R736	1k	
	R737	220k	
	R738	10k	
	R742	10k	
	R746	10k	
	R747	1k	
	R748	1k	
	R749	1k	
	R750	2.2k	
	R751	2.2k	
	RY701	Fujitsu FTR-F1CA012V	
	U701	LTS 25-NP	
	U702	TL074	
	U703	74S00	
	U704	LM239 or MC3302p	
	U705	LM7812	
	U706	LM7912	
	U707	LM7805	